

drought tips

Number 92-29

Irrigation Water Management Made Simple

Effective water management requires knowing the relationships between flowrate into the field, acres irrigated, irrigation times, and the amount of applied water. The following equation can be used to provide this information:

$$Q \times T = 449 \times A \times D$$

where Q = flow rate of water being applied to the field in gallons per minute;

T = actual hours used to irrigate the field;

A = acres irrigated;

D = the gross depth to be applied, which includes soil moisture replenishment plus deep percolation and surface runoff (surface irrigation only).

The following questions can be answered using this equation:

• *How many inches of water are applied during an irrigation?*

$$D = \frac{Q \times T}{449 \times A}$$

Example 1: How many inches are applied to 40 acres where the pump flow rate is 300 gpm and irrigation time is 22 hours per day for 10 days?

Q = 300 gpm;

A = 40 acres;

T = 22 hours per day x 10 days
= 220 hours.

$$D = \frac{300 \text{ gpm} \times 220 \text{ hour}}{449 \times 40 \text{ acres}} \\ = 3.7 \text{ inches}$$

• *What flow rate is needed to irrigate the field?*

$$Q = \frac{449 \times A \times D}{T}$$

Example 2: What flow rate is needed to apply 3 inches of water over 100 acres with a total irrigation time of 180 hours?

$$Q = \frac{449 \times 100 \text{ acres} \times 3 \text{ inches}}{180 \text{ hours}} \\ = 748 \text{ gallons per minute}$$

• *How many acres can I irrigate with my water supply?*

$$A = \frac{Q \times T}{449 \times D}$$

Example 3: How many acres can I irrigate with a flow rate of 200 gpm? The desired depth to be applied is 3 inches per set, each set is 12 hours long, and the number of sets is 10.

$$T = 12 \text{ hours per set} \times 10 \text{ sets} \\ = 120 \text{ hours}$$

$$A = \frac{200 \text{ gpm} \times 120 \text{ hours}}{449 \times 3 \text{ inches}} \\ = 17.8 \text{ acres, or } 18 \text{ acres}$$

• *How long should I irrigate?*

$$T = \frac{449 \times A \times D}{Q}$$

Example 4: How long should I operate my irrigation system to apply 4 inches over 80 acres? The flow rate into the field is 600 gpm.

$$T = \frac{449 \times 80 \text{ acres} \times 4 \text{ inches}}{600 \text{ gpm}} \\ = 239 \text{ hours of operation}$$

drought tips is a publication series developed as a cooperative effort by the following organizations:

California Department of Water Resources — Water Conservation Office
University of California (UC)
UC Department of Land, Air and Water Resources
USDA Drought Response Office
USDA Soil Conservation Service

The University of California, in compliance with Titles VI and VII of the Civil Rights Act of 1964, Title IX of the Education Amendments of 1972, Sections 503 and 504 of the Rehabilitation Act of 1973, and the Age Discrimination Act of 1975, does not discriminate on the basis of race, religion, color, national origin, sex, mental or physical handicap, or age in any of its programs or activities, or with respect to any of its employment policies, practices, or procedures. Nor does the University of California discriminate on the basis of ancestry, sexual orientation, marital status, citizenship, medical condition (as defined in section 12926 of the California Government Code) or because individuals are special disabled veterans or Vietnam era veterans (as defined by the Vietnam Era Veterans Readjustment Act of 1974 and Section 12940 of the California Government Code). Inquiries regarding this policy may be addressed to the Affirmative Action Director, University of California, Agriculture and Natural Resources, 300 Lakeside Drive, 6th Floor, Oakland, CA 94612-3560. (510) 987-0097.

Edited by Anne Jackson, UC Department of Land, Air and Water Resources
Published 1992